




ATLAS

BOOSTED OVERDRIVE

OWNER'S MANUAL

Your **GAMMA SERIES** Atlas Boosted Overdrive from Acoustic Control Corporation allows you to add nuanced, tube amp-style overdrive to your guitar sound, with a Boost switch that pushes low frequencies and adds more high end bite to the drive sound. This distortion preserves your dynamics and articulation, and is nicely responsive to volume, tone and pickup adjustments you make on your guitar. It's all built into a road-ready metal chassis with metal knobs, operating from either a 9-volt battery, or 9-volt DC power supply.



FEATURES:


- Tube amp-style overdrive that preserves dynamics, articulation and guitar character
- Boost switch enhances low frequencies, and adds more high end bite to the drive sound
- All metal chassis and knobs and a road-ready design
- Simple operation for easy access to essential sound for electric guitar
- Operates from a 9-volt battery or 9V DC adapter (battery and DC supply not included)
- Mono audio input and output, with buffered bypass for consistent tone in any setup

SPECIFICATIONS:


Power Input Compatibility 9V DC (Center Negative) Power Draw 15mA	Input ¼" Instrument Level Input (650k Ohms Impedance)	Dimensions 4.59 in (D) x 27.5 in (W) x 2.19 in (H)
Battery Compatibility 9V (Alkaline recommended) 50 Hours Run Time	Output ¼" Instrument Level Output (1k Ohms Impedance)	Weight .55 Lbs (8.8 oz)

CUSTOMER SUPPORT & SERVICE

For product questions or customer service, please visit www.AcousticControlCorp.com, or call us at (855) 272-1090, Monday-Friday 8:00 a.m.-5:00 p.m. MST.



Underside of pedal
(Bottom removed for battery access)



1. DC 9V Power Input Jack

You can power your GAMMA Series pedal from a 9-volt regulated DC adapter (plug polarity is positive on the barrel and negative in the center).

2. Battery Capability

Use a Phillips head screwdriver to remove 4 bottom screws to access battery connection. High quality alkaline 9-volt battery can be used for approximately 50 hours of continual operation. If pedal won't operate when battery is installed, battery may be discharged, and should be replaced with a fresh, fully-charged battery. Or connect a compatible power supply for non-battery operation.

3. Footswitch

Push down the footswitch to toggle between on and bypass status.

4. LED

When the LED is lit, the effect is on. When it's off, the effect is bypassed.

5. INPUT Jack

1/4" mono audio jack, to receive the signal from your guitar or a previous pedal. Pedal draws power only when this jack has a plug inserted.

6. OUTPUT Jack

1/4" mono audio jack, outputs the signal.

7. BOOST SWITCH

Boost setting adds low frequency energy, and adds more high end bite to the DRIVE.

8. LEVEL Knob

Adjusts output level (volume).

9. DRIVE Knob

Adjusts the amount of distortion.

10. TONE Knob

Adjusts the high frequency response, from dark to bright. Try the center (noon) position as a starting point.